


W211/R230 Repair Tool

1. Connect cable to sbc
2. Power 12v 
3. Select [sbc info]-[ok]
4. Select [fix sbc]-[ok]-wait ~10s
5. Remove power
6. Remove cable from sbc

