

iCar OBD II Adapter	Support all OBD II protocols	Support iOS OBD II Apps(recommended)	Support Android OBD II Apps(recommended)	Auto sleep mode	Auto Wake up mode	Power consumption <Standby current>
iCar Lx BT3.0	✓		Torque/Geekobd/Dashcommand			<30Ma
iCar1 WIFI	✓	Dashcommand/Accurate	Torque/Dashcommand			<30Ma
iCar1 BT3.0	✓		Torque/Geekobd/Dashcommand			<30Ma
iCar1 BLE4.0	✓	Geekobd/Accurate	Torque/Geekobd/Dashcommand			<30Ma
iCar2 WIFI	✓	Dashcommand/Accurate	Torque/Dashcommand	✓		<30Ma
iCar2 BT3.0	✓		Torque/Geekobd/Dashcommand	✓		<30Ma
iCar2 BLE4.0	✓	Geekobd/Accurate	Torque/Geekobd/Dashcommand	✓		<30Ma
iCar3 WIFI	✓	Dashcommand/Accurate	Torque/Dashcommand	✓		<30Ma
iCar3 BT3.0	✓		Torque/Geekobd/Dashcommand	✓		<30Ma
iCar3 BLE4.0	✓	Geekobd/Accurate	Torque/Geekobd/Dashcommand	✓		<30Ma
iCar Pro II WIFI	✓	Dashcommand/Accurate	Torque/Geekobd/Dashcommand	✓	✓	<3mA
iCar Pro BT3.0	✓		Torque/Geekobd/Dashcommand	✓	✓	<3mA
iCar Pro BLE4.0	✓	Geekobd/Accurate	Torque/Geekobd/Dashcommand	✓	✓	<3mA

(OBDBEST iCar Pro II OBD II adapter product table 1)

5. Package list:

- 1-OBDBEST iCar Pro II OBDII adapter
- 1-User manual

6. Setting guide:

1) BT3.0 model version

Home screen→Go to setting page,select V-LINK→Default password is "1234"→Device paired→Run Torque app→Go to Torque app OBD II adapter setting,Choose connection type>Bluetooth,choose Bluetooth device>V-LINK →Exit Torque app completely→Run Torque app→Connected

2)BLE4.0 Dual mode version:

- Android:<Torque App>
Home screen→Go to setting page,select V-LINK→Default password is "1234"→Device paired→Run Torque app→Go to Torque app OBD II adapter setting,Choose connection type>Bluetooth,choose Bluetooth device>V-LINK→Exit Torque app completely→Run Torque app→Connected
- iOS:<Accurate app>
Home screen→Go to setting page,click on Bluetooth function(Device name is invisible)→Run Accurate app→Go to Accurate app setting page, select Bluetooth and connect→Exit Accurate app and run again→Connected

3)Wi-Fi version

- Android <Torque app>
Home screen →Go to setting page,open Wi-Fi→Run Torque app→Go to Torque app OBD II adapter settings , choose connection type>Wi-Fi, then set Wi-Fi preferences in the same page,IP address is 192.168.0.10. Port is 35000→Exit Torque app completely →Run Torque app →Connected
- iOS <Accurate>

Home screen→Go to setting page,Open Wi-Fi , Select V-LINK →Run Accurate app→Go to Accurate app setting page,select Wi-Fi →Exit app completely →Run Accurate app again →Connected

7. Cautions & Warnings:

Please read following tips before you use the OBDBEST iCar Pro II OBD II adapter

- Please plug the OBDII adapter correctly into your car by following the installation instructions before operating.
- When driving the car,please do not operate this unit.Any distraction may cause an accident.
- OBDII adapter communicates with cars via Wi-Fi/BT.Please do not use this product in the places with strong electro-magnet interference in order to ensure preper communication.

*Various wireless connection mode : All iCar OBD II adapter have Wi-Fi and Bluetooth (BT3.0/ BLE4.0)model.Please refer to the table 1 for more details.

OBDBEST



www.obdbest.com

OBDBEST

OBDBEST iCar Pro II Wifi

User Manual
(BT3.0 / BLE4.0 / WIFI)

Thanks for using this product.Please read this manual carefully before any operating.This manual guides the users how to use iCar Pro II Wifi OBDII adapter.Please read the warnings on the last page before using the product.

1. Introductions

iCar Pro II Wifi OBD II adapter is a powerful car diagnostic tool developed by Shenzhen OBDBEST Electronr Co.,Ltd It is compliant with full OBD II/EOBD specifications.Various wireless connection modes* to connect your smartphone or pad. It reads the real-time car engine data, such as engine speed, ignition time, fuel trim, water temperature, fuel consumption.It support a variety of OBD II apps.



2. Electrical specifications

- Supply Voltage: 11.5V—15V
- Supply Current: <200mA
- Standby Current: <30mA (iCar Pro=<3mA)
- Operating Temperature: -40℃—85℃
- Operating Humidity : 5%~95%RH Non-Dewfall

3.OBDBEST iCar Pro II OBD II adpater is a high-qua lity automotive scanning tool,suppotrts all OBD-II protocols:

- SAE J1850 PWM(41.6 Kbaud)
- SAE J1850 VPW(10.4 Kbaud)
- ISO9141-2(5 baud init,10.4 Kbaud)
- ISO14230-4 KWP(5 baud init,10.4 Kbaud)
- ISO14230-4 KWP(fast init,10.4 Kbaud)
- ISO15765-4 CAN(1 1bit ID,500 Kbaud)
- ISO15765-4 CAN(29bit ID,500 Kbaud)
- ISO15765-4 CAN(1 1bit ID,250 Kbaud)
- ISO15765-4 CAN(29bit ID,250 Kbaud)
- SAE J1939 CAN(29bit ID,250* Kbaud)
- USER1 CAN(11*bit ID,125* Kbaud)
- USER2 CAN(11*bit ID,50* kbaud)
- *default settings (user adjustable)

4. Features:

- Read diagnostic trouble codes, both generic and manufacturer-specific, and display their meaning. (over 3000 generic code definitions in the database).
- Clear trouble codes and turn off the MIL ("Check Engine" light)
- Engine RPM
- Calculated Load Value
- Coolant Temperature

- Fuel System Status
- Vehicle Speed
- Short Term Fuel Trim
- Long Term Fuel Trim
- Intake Manifold Pressure
- Many others -
- Oxygen sensor voltages/associated short term fuel trims
- Timing Advance
- Intake Air Temperature
- Air Flow Rate
- Absolute Throttle Position
- Fuel System status
- Fuel Pressure

Vehicle Coverage:

Works on all OBD2 Vehicles (1996 onwards in USA) and EOBD vehicles (Petrol cars from 2001 and diesel cars from 2003/2004 in Europe)

For your information:

For your vehicle to be OBD II compliant it must have a 16-pin DLC (Data Link Connector) under the dash and the Vehicle Emission Control Information Label must state that the vehicle is OBD II compliant. To be sure your vehicle complies with OBD-II, look for a sticker on the vehicle under the hood in the engine compartment that clearly states "OBD II compliant or certified" . An example of the sticker is shown below



OBDBEST CERTIFIED

